

Japon Citizen 82S7



**HISLON**  
**1928**

Kullanım Kılavuzu


---

User Guide

KULLANIM KILAVUZU - Japon Citizen 82S7

Hislon TM253 Modellerinde Geçerlidir.

A) EKCRAN GÖRÜNTÜSÜ



B) SAATİN KURULMASI

Saatiniz kol hareketi ile otomatik olarak kurulmaktadır.

\* Diğer bir seçenek olarak; Kurma Kolu'nu saat yönünde birkaç kez çevirerek saatinizi kurabilirsiniz.

C) SAATİN AYARLANMASI


- 1) Kurma Kolu'nu 1. Pozisyon'a çekin.
- 2) Kurma Kolu'nu çevirerek saatinizi ayarlayın.
- 3) Kurma Kolu'nu ilk pozisyona (Normal Pozisyon) geri getirin.

\* 24 Saat Göstergesi, Akrep ve Yelkovan ile birlikte hareket etmektedir, 12-24 (AM-PM) saat dilimini doğru ayarladığınızdan emin olun.

**USER GUIDE - Japon Citizen 82S7**

**Applies to TM253 Hislon Models**

**A) DISPLAYS AND BUTTONS**



**B) WINDING THE MAINSPRING**

Automatic winding watch can also be hand wound by turning the crown clockwise in Normal position.

Wind several times clockwise. It will start to move naturally.

**C) SETTING THE TIME**

- 1) Pull the crown out to the 1st Click Position.
- 2) Turn the crown to set hour and minute hands.
- 3) After the time has been set, push the crown back to the Normal position.

\*24Hour hand moves linked with the center Hour and Minute hand.

**These specifications might be changed without prior notice.**